
INITIAL MEASUREMENT GUIDE






Before we can work up your FREE 3-D design & quote we will need some basic measurements. Do the best you can for now. Professional measurements will be taken later in the process.

- Step 1 Draw an outline of the room where you will be installing new cabinets. This outline represents all the walls in the room as seen from above (also known as a floorplan).
- Step 2 Draw two short lines to indicate the outside edge of the trim of each window and door in the room.
- Step 3 Starting from the left and continuing clockwise around the room, label each wall segment, window and door with a single letter (A-T).
- Step 4 Using a tape measure, measure each segment in the room (A-T) and record it in the spaces below.
- Step 5 Draw boxes to indicate where you would like your appliances to be located in your newly designed space.
- Step 6 Take photos of this completed document plus a few general photos of the space to be remodeled and either bring it in for your design consultation or email it to your designer in advance of the consultation.

Additional Measurements

| Additional Measurements | | | | | |
|--|---------------|-----|--------|--|--|
| Ceiling Height 9 | 8 inch | ies | | | |
| If applicable please record the following: | | | | | |
| Soffit/Bulkhead Heigh | t (from flooi | 84 | _ inch | | |
| Ceiling Beam Height (| from floor) | i | inches | | |

INITIAL MEASUREMENT GUIDE





Before we can work up your FREE 3-D design & quote we will need some basic measurements. Do the best you can for now. Professional measurements will be taken later in the process.

| Step 1 - Draw an outline of the room where you will be installing new cabinets. This outline represents all the walls in the room as seen from above (also known as a floorplan). |
|---|
| Step 2 - Draw two short lines to indicate the outside edge of the trim of each window and door in the room. |
| Step 3 - Starting from the left and continuing clockwise around the room, label each wall segment, window and door with a single letter (A-T). |
| Step 4 - Using a tape measure, measure each segment in the room (A-T) and record it in the spaces below. |
| Step 5 - Draw boxes to indicate where you would like your appliances to be located in your newly designed space. |
| Step 6 - Take photos of this completed document plus a few general photos of the space to be remodeled and either bring it in for your design consultation or email it to your designer in advance of the consultation. |

Additional Measurements

| Ceiling Height | _ inches | |
|------------------------------------|-----------|--------|
| If applicable please record the fo | ollowing: | |
| Soffit/Bulkhead Height (fro | m floor) | inches |
| Ceiling Beam Height (from | floor) | inches |