


# INITIAL MEASUREMENT GUIDE



Before we can work up your FREE 3-D design & quote we will need some basic measurements. Do the best you can for now. Professional measurements will be taken later in the process.

- ✓ Step 1 - Draw an outline of the room where you will be installing new cabinets. This outline represents all the walls in the room as seen from above (also known as a floorplan).
- ✓ Step 2 - Draw two short lines to indicate the outside edge of the trim of each window and door in the room (See sample).
- ✓ Step 3 - Starting from the left and continuing clockwise around the room, label each wall segment, window and door with a single letter (A-T, See sample).
- ✓ Step 4 - Using a tape measure, measure each segment in the room (A-T) and record it in the spaces below.
- ✓ Step 5 - Draw boxes to indicate where you would like your appliances to be located in your newly designed space.
- ✓ Step 6 - Take photos of this completed document plus a few general photos of the space to be remodeled and either bring it in for your design consultation or email it to your designer in advance of the consultation.

|                      |                      |  |  |
|----------------------|----------------------|--|--|
| <b>A</b> = 48 inches | <b>F</b> = 42 inches | <b>K</b> = 50 inches                   | <b>P</b> = <input type="text"/> inches |
| <b>B</b> = 42 inches | <b>G</b> = 28 inches | <b>L</b> = <input type="text"/> inches | <b>Q</b> = <input type="text"/> inches |
| <b>C</b> = 38 inches | <b>H</b> = 42 inches | <b>M</b> = <input type="text"/> inches | <b>R</b> = <input type="text"/> inches |
| <b>D</b> = 42 inches | <b>I</b> = 33 inches | <b>N</b> = <input type="text"/> inches | <b>S</b> = <input type="text"/> inches |
| <b>E</b> = 30 inches | <b>J</b> = 32 inches | <b>O</b> = <input type="text"/> inches | <b>T</b> = <input type="text"/> inches |

## Additional Measurements

Ceiling Height 98 inches

If applicable please record the following:

Soffit/Bulkhead Height (from floor) 84 inches

Ceiling Beam Height (from floor) \_\_\_\_\_ inches

# INITIAL MEASUREMENT GUIDE



**DO NOT MEASURE YOUR EXISTING CABINETS OR COUNTERTOPS**

Measure ONLY walls, windows, doors & ceiling height

Please include the width of the trim in each window or door measurement

Before we can work up your FREE 3-D design & quote we will need some basic measurements. Do the best you can for now. Professional measurements will be taken later in the process.

- Step 1 - Draw an outline of the room where you will be installing new cabinets. This outline represents all the walls in the room as seen from above (also known as a floorplan).
- Step 2 - Draw two short lines to indicate the outside edge of the trim of each window and door in the room (See sample).
- Step 3 - Starting from the left and continuing clockwise around the room, label each wall segment, window and door with a single letter (A-T, See sample).
- Step 4 - Using a tape measure, measure each segment in the room (A-T) and record it in the spaces below.
- Step 5 - Draw boxes to indicate where you would like your appliances to be located in your newly designed space.
- Step 6 - Take photos of this completed document plus a few general photos of the space to be remodeled and either bring it in for your design consultation or email it to your designer in advance of the consultation.

|   |   |   |   |
|---|---|---|---|
| <b>A</b> = <input style="width: 40px;" type="text"/> inches | <b>F</b> = <input style="width: 40px;" type="text"/> inches | <b>K</b> = <input style="width: 40px;" type="text"/> inches | <b>P</b> = <input style="width: 40px;" type="text"/> inches |
| <b>B</b> = <input style="width: 40px;" type="text"/> inches | <b>G</b> = <input style="width: 40px;" type="text"/> inches | <b>L</b> = <input style="width: 40px;" type="text"/> inches | <b>Q</b> = <input style="width: 40px;" type="text"/> inches |
| <b>C</b> = <input style="width: 40px;" type="text"/> inches | <b>H</b> = <input style="width: 40px;" type="text"/> inches | <b>M</b> = <input style="width: 40px;" type="text"/> inches | <b>R</b> = <input style="width: 40px;" type="text"/> inches |
| <b>D</b> = <input style="width: 40px;" type="text"/> inches | <b>I</b> = <input style="width: 40px;" type="text"/> inches | <b>N</b> = <input style="width: 40px;" type="text"/> inches | <b>S</b> = <input style="width: 40px;" type="text"/> inches |
| <b>E</b> = <input style="width: 40px;" type="text"/> inches | <b>J</b> = <input style="width: 40px;" type="text"/> inches | <b>O</b> = <input style="width: 40px;" type="text"/> inches | <b>T</b> = <input style="width: 40px;" type="text"/> inches |

## Additional Measurements

Ceiling Height \_\_\_\_\_ inches

If applicable please record the following:

Soffit/Bulkhead Height (from floor) \_\_\_\_\_ inches

Ceiling Beam Height (from floor) \_\_\_\_\_ inches